# IQS-1500

# **CALIBRATION POWER METER**



Resolution of 0.001 dB and linearity of  $\pm$  0.010 dB—one of the most accurate power meters on the market.

# **KEY FEATURES**

Operates in the WDM window

Enables on-site power-meter calibration

Linearity of  $\pm$  0.01 dB

5 mm cooled detector

# **COMPLEMENTARY PRODUCTS**







WDM Laser Source IQS-2400 Variable Attenuator IQS-3150

Utility Module IQS-9600



# DELIVERING ACCURATE POWER MEASUREMENTS

Enjoy exceptional performance, flexibility, ease of use and extensive integration capabilities with EXFO's IQS-1500 Calibration Power Meter. Like all IQS products, this module features PC-based software and a standardized graphical user interface (GUI). What's more, the IQS-1500 offers very low uncertainty (± 2 % to 3 %) and high-performance linearity (± 0.01 dB). The Q1 model is calibrated at the National Institute of Standards and Technology (NIST), providing an uncertainty of as little as 0.9 % for three user-selected wavelengths.

The IQS-1500 comes with a 5 mm cooled germanium detector (750 nm to 1800 nm), delivering high accuracy—even at unstable temperatures—over a wide dynamic range.

# **Enabling In-House Verification and Calibration of Power Meters**

Combine the IQS-1500 with the IQS-2400 WDM Laser Source (DFB laser) to perform in-house power-meter verification and calibration. The NIST-calibrated IQS-1500-Q1 model provides < ±0.9 % uncertainty at reference conditions, which enables local calibration of all optical power meters.

Because its central wavelength can easily be pinpointed, a DFB laser source such as the IQS-2400 is ideal for calibrating both at 1310 nm and 1550 nm. Use its coherence control setting to modulate the signal, therefore minimizing interference.



Housed in the IQS-600 Integrated Qualification System, the IQS-1500 Calibration Power Meter features user-friendly, flexible, Windows-compatible software, and allows you to easily select all configuration parameters from a single setup window.

The IQS-1500 also offers two operation modes: standard power measurement or calibration. A complete step-by-step procedure guides you through the power-meter calibration operation for systematic, repeatable and scientifically valid results. Experienced users can access individual steps directly from the main window.

This procedure yields a detailed calibration report (in HTML format), with total calibration uncertainty for each calibrated wavelength. Data can be saved on a floppy disk, the system's hard drive or a remote controller station, making storage space practically limitless. Thanks to Windows-based software, the IQS-1500 can be used in conjunction with any compatible system.



A typical power-measurement setup.



# **CALIBRATION MODE**

The IQS-1500's Windows-compatible, highly intuitive GUI allows for easy control via mouse, touchscreen or keyboard. In addition, it allows you to save multiple user configurations and access the instrument's online user guide.

#### A- Start

Allows the user to select the calibration mode, start a new calibration sequence with template file, or view a report file.

#### **B-Information**

Allows the user to enter general and specific information about current measurement conditions. This information will be included in the calibration summary.

#### **C- General**

Contains the user and module information currently being used to perform calibration.

#### **D-Conditions**

Contains all information related to the conditions used to perform calibration, including source wavelength, power, bandwidth, temperature and humidity.

#### E- Device under Test (DUT)

Contains all information related to the DUT under calibration.

#### F- Uncertainties

Allows the user to enter specific information related to the calibration uncertainty calculation.

#### **G- Null**


Allows the user to ensure accuracy by eliminating electronic offsets and dark currents.

#### **H- Calibration**

Allows the user to perform calibration measurements and calculations.

#### I- Ref. Meter Measurement

This auto-save function allows the user to select the number of measurements and the intervals between readings for automated measurements on the reference power meter (IQS-1500).



#### J- DUT Measurements


Allows the user to enter DUT power measurements.

### K-Summary

Displays complete calibration results, including mean power, calibration factor and total uncertainty.

#### L- Detailed calibration reports

Generates detailed calibration reports that include instrumentation identification, environmental information, reference conditions and a calibration summary for each wavelength.





SPECIFICATIONS*			
Model	IQS-1502-Q0	IQS-1502-Q1	
Detector type	Ge Ge		
Detector size (mm)	5 5		
Power range a (dBm)	+5 to -60 +5 to -60		
Wavelength range (nm)	750 to 1800 750 to 1800		
Linearity a, b (dB)	± 0.01 (+5 dBm to -50 dBm) ± 0.01 (+5 dBm to -50 dBm)		
Uncertainty <sup>f</sup>	$\pm~2~\%^{\circ}$ (at 1310.0 $\pm~0.1$ nm and 1550.0 $\pm~0.1$ nm) (0 dBm to $-10$ dBm CW)	≤ ± 0.9 %4 at 3 λ (-10 dBm CW)	
	± 3 %° (750 nm to 1700 nm) (-30 dBm to -40 dBm CW)	± 3 % <sup>d</sup> (750 nm to 1700 nm) (-30 dBm to -40 dBm CW)	
Power resolution (dB)	0.001		
Wavelength resolution (nm)	0.1		
Applicable fiber type (µm)	9/125 (B); 50/125 (C); 62.5/125 (D) 9/125 (B); 50/125 (C); 62.5/125 (D)		

GENERAL SPECIFICATIONS		
Temperature operating storage	23 °C to 5 °C -40 °C to 70 °C	(73 °F to 9 °F) (–40 °F to 158 °F)
Relative humidity	0 % to 80 % noncondensing	
Size (H x W x D) (module only)	12.5 cm $\times$ 3.6 cm $\times$ 28.2 cm	(4 <sup>15</sup> /16 in x 1 <sup>7</sup> /16 in x 11 <sup>1</sup> /8 in)
Weight (module only)	0.63 kg	(1.4 lb)

## STANDARD ACCESSORIES

User guide, fiber-optic adapter (FOA), one reference test jumper and Certificate of Calibration

- a. At 1310 nm and 1550 nm.
- c. Q0 option, uncertainty at EXFO reference conditions:
- $\bullet \pm 2 \ \% \ uncertainty \ at \ (1310.0 \pm 0.1) \ nm \ and \ (1550.0 \pm 0.1) \ nm, with \ 9/125 \ \mu m \ (B) \ fiber, \ and \ source \ spectral \ width \ (FWHM) < 10 \ nm.$
- ± 3 % uncertainty from 750 nm to 1700 nm, with 62.5/125 µm (D) fiber, and source spectral width (FWHM) ≤ 12 nm.
- FC/UPC connector (ceramic ferrule) with FOA-322.
- d. Q1 option, calibration at NIST
- 1)  $\leq \pm 0.9$  % uncertainty at three user-specified wavelengths within the following ranges at NIST reference conditions:

786 nm  $\pm$  0.5 nm (840 to 860) nm  $\pm$  0.25 nm (1280 to 1330) nm  $\pm$  0.25 nm (1520 to 1625) nm  $\pm$  0.25 nm

- 9/125 to 62.5/125 µm (B to D) fiber
- FC\_ST or SC connector
- Fiber-optic adapter (FOA) used at NIST
- Source spectral width (FWHM) < 10 nm
- 2)  $\pm$  3 % uncertainty from 750 nm to 1700 nm, 62.5/125 µm (D) fiber, source spectral width (FWHM) < 12 nm, and FC/UPC connector (ceramic ferrule) with FOA-322.
- e. See Ordering Information for details.
- f. All uncertainties are valid on the day of calibration after a warm-up time of 20 minutes, and specified with a 95 % confidence level.



#### **ORDERING INFORMATION**

#### IQS-150X-XX-X-XX

Model

| CS-1502-Q0-B = 5 mm TEC-Ge detector, 2 % uncertainty at (1310 ± 0.1) nm and (1550 ± 0.1) nm, singlemode 9/125 μm
| CS-1502-Q1-B = 5 mm TEC-Ge detector, 0.9 % uncertainty calibrated at NIST, singlemode 9/125 μm
| CS-1502-Q1-C = 5 mm TEC-Ge detector, 0.9 % uncertainty calibrated at NIST, multimode 50/125 μm
| CS-1502-Q1-D = 5 mm TEC-Ge detector, 0.9 % uncertainty calibrated at NIST, multimode 62.5/125 μm
| CS-1502-Q1-D = 5 mm TEC-Ge detector, 0.9 % uncertainty calibrated at NIST, multimode 62.5/125 μm
| CS-1502-Q1-D = 5 mm TEC-Ge detector, 0.9 % uncertainty calibrated at NIST, multimode 62.5/125 μm
| CS-1502-Q1-D = 5 mm TEC-Ge detector, 0.9 % uncertainty calibrated at NIST, multimode 62.5/125 μm
| CS-1502-Q1-D = 5 mm TEC-Ge detector, 0.9 % uncertainty calibrated at NIST, multimode 62.5/125 μm
| CS-1502-Q1-D = 5 mm TEC-Ge detector, 0.9 % uncertainty calibrated at NIST, multimode 62.5/125 μm
| CS-1502-Q1-D = 5 mm TEC-Ge detector, 0.9 % uncertainty calibrated at NIST, multimode 62.5/125 μm
| CS-1502-Q1-D = 5 mm TEC-Ge detector, 0.9 % uncertainty calibrated at NIST, multimode 62.5/125 μm
| CS-1502-Q1-D = 5 mm TEC-Ge detector, 0.9 % uncertainty calibrated at NIST, multimode 62.5/125 μm
| CS-1502-Q1-D = 5 mm TEC-Ge detector, 0.9 % uncertainty calibrated at NIST, multimode 62.5/125 μm
| CS-1502-Q1-D = 5 mm TEC-Ge detector, 0.9 % uncertainty calibrated at NIST, multimode 62.5/125 μm
| CS-1502-Q1-D = 5 mm TEC-Ge detector, 0.9 % uncertainty calibrated at NIST, multimode 62.5/125 μm
| CS-1502-Q1-D = 5 mm TEC-Ge detector, 0.9 % uncertainty calibrated at NIST, multimode 62.5/125 μm
| CS-1502-Q1-D = 5 mm TEC-Ge detector, 0.9 % uncertainty calibrated at NIST, multimode 62.5/125 μm
| CS-1502-Q1-D = 5 mm TEC-Ge detector, 0.9 % uncertainty calibrated at NIST, multimode 62.5/125 μm
| CS-1502-Q1-D = 5 mm TEC-Ge detector, 0.9 % uncertainty calibrated at NIST, multimode 62.5/125 μm
| CS-1502-Q1-D = 5 mm TEC-Ge detector, 0.9 % uncertainty calibrated at NIST, multimode 62.5/125 μm
| CS-1502-Q1-D = 5 mm TEC-Ge detector, 0.9 % u

#### Notes

- a. Test jumper FC/UPC only.
- b. Singlemode only.
- c. Multimode only.

EXFO Headquarters > Tel.: +1 418 683-0211 | Toll-free: +1 800 663-3936 (USA and Canada) | Fax: +1 418 683-2170 | info@EXFO.com | www.EXFO.com

EXFO serves over 2000 customers in more than 100 countries. To find your local office contact details, please go to www.EXFO.com/contact.

EXFO is certified ISO 9001 and attests to the quality of these products. EXFO has made every effort to ensure that the information contained in this specification sheet is accurate. However, we accept no responsibility for any errors or omissions, and we reserve the right to modify design, characteristics and products at any time without obligation. Units of measurement in this document conform to SI standards and practices. In addition, all of EXFO's manufactured products are compliant with the European Union's WEEE directive. For more information, please visit www.EXFO.com/recycle. Contact EXFO for prices and availability or to obtain the phone number of your local EXFO distributor.

For the most recent version of this spec sheet, please go to the EXFO website at www.EXFO.com/specs.

In case of discrepancy, the Web version takes precedence over any printed literature.



