



Introduction

The 8612xx family of multi-wavelength meters is known for reliability and durability on the manufacturing floor, on engineer's benches, and it is robust enough to be installed on ships. Statistical data from a large share of the industry's installed wavelength meters enables Keysight Technologies, Inc. to continuously fine-tune its instruments for lower cost of ownership and longer usage. Current updates include an extended recommended re-calibration period of two years and a doubled lifetime of the built-in reference laser. The 86122C multi-wavelength meter includes five years, the 86120B and 86120C three years of warranty without additional cost. The warranty covers not only the reference laser, but all opto-mechanical and electronic parts.

NEW Fast Update Option for the 86122C Multi-Wavelength Meter

Our flagship model, the Keysight 86122C, is now available with a faster update rate. The new option 86122C-110 accelerates the update rate from 2 per second to 3 per second. The measurement cycle time is reduced from 0.5 seconds to 0.3 seconds. For compatibility, the previous update rate is still available under option 86122C-100.

Keysight multi-wavelength meters are Michelson interferometerbased instruments that measure wavelength and optical power of laser light over a specified wavelength range. Simultaneous measurements of multiple laser lines are performed allowing measurements of DWDM signals and multiple lines of Fabry-Perot lasers. Each laser line is assumed to have a linewidth (including modulation sidebands) of less than:

- 10 GHz for the 86120B,
- 5 GHz for the 86120C and
- 2.5 GHz for the 86122C

This technical specifications sheet describes the measurement accuracy and operating conditions of the Keysight 86120B, 86120C and 86122C Multi-Wavelength Meters. The specifications apply to all functions within the specified environmental conditions. All specifications apply after the instrument's temperature has been stabilized after 15 minutes continuous operation, and when the instrument is in NORMAL UPDATE mode (86120B and 86120C).

Definitions of Terms

Characteristics and specifications

The distinction between specifications and characteristics is described as follows:

- Specifications describe warranted performance.
- Characteristics provide useful, but non-warranted information about the functions and performance of the instrument.
- General Characteristics give additional information for using the instrument. These are general descriptive terms that do not imply a level of performance.

Wavelength

- Range refers to the allowable wavelength range of the optical input signal.
- Absolute accuracy indicates the maximum wavelength error over the allowed environmental conditions.
- Differential accuracy indicates the maximum wavelength error in measuring the wavelength difference between two signals that are simultaneously present.
- Minimum resolvable separation indicates the minimum wavelength separation of two laser lines input required to measure each wavelength simultaneously. Two laser lines closer in wavelength than the minimum resolvable separation are not resolved and one average wavelength is displayed.
- Display resolution indicates the minimum incremental change in displayed wavelength.

Power

- Calibration accuracy indicates the maximum power calibration error at the specified wavelengths over the allowed environmental conditions.
- Flatness refers to the maximum amplitude error in a measurement between two lines that are separated in wavelength by no more than the specified amount.
- Linearity indicates the maximum power error in measuring the change in power of one laser line.
- Polarization dependence indicates the maximum displayed power variation as the polarization of the input signal is varied.
- Display resolution indicates the minimum incremental change in displayed power.

Sensitivity

Sensitivity is defined as the minimum power level of a single laser line input to measure wavelength and power accurately. A laser line with less than the minimum power may be measured but with reduced wavelength and power accuracy. For multiple laser lines input, sensitivity may be limited by total input power.

Selectivity

Selectivity indicates the ability to measure the wavelength and power of a weak laser line in the proximity of a specified stronger laser line and separated by the specified amount.

Input power

- Maximum displayed level indicates the maximum total input power (total of all laser lines present) to accurately measure wavelength and power.
- Maximum safe input power indicates the maximum total input power (total of all laser lines present) to avoid permanent optical damage to the instrument.

Maximum number of lines input

Maximum number of lines input is the maximum number of displayed lines. If more than the specified number of lines is input, only the longest wavelength lines are displayed.

Input return loss

Input return loss indicates the optical power reflected back to the user's fiber cable relative to the input power. It is limited by the return loss of the front panel connector, and assumes the user's connector is good.

Measurement cycle time

Measurement cycle time refers to the cycle time when measuring wavelength and power of laser lines. Specific advanced applications may require longer cycle times.

Specifications

	86120B	86120C	86122C	Notes
Wavelength				
Range	700 to 1650 nm (182 to 428 THz)	1270 to 1650 nm (182 to 236 THz)	1270 to 1650 nm (182 to 236 THz)	For lines separated by less than the specified
Absolute accuracy	(102 00 120 1112)	(102 10 200 1112)	(102 10 200 1112)	amount, wavelength
···· ,	±3 ppm	±2ppm	± 0.2 ppm	accuracy is reduced.
At 1550 nm	± 0.005 nm	± 0.003 nm	± 0.3 pm	_ ,
At 1310 nm	± 0.004 nm	± 0.003 nm	± 0.3 pm	_
For laser lines separated by	≥ 30 GHz	≥ 15 GHz	≥ 10 GHz	_
Differential accuracy ¹	± 2 ppm	±1ppm	± 0.15 ppm	-
Minimum resolvable separation	on ¹ (equal power lines input)			
-	20 GHz	10 GHz	5 GHz	
At 1550 nm	0.16 nm	0.08 nm	0.04 nm	-
At 1310 nm	0.11 nm	0.06 nm	0.03 nm	_
For laser lines separated by	≥ 30 GHz	≥ 15 GHz	≥ 10 GHz	_
Display resolution				
	0.001 nm		0.0001 nm	
Fast update mode	0.01 nm		N/A	
Units	nm (vacuum or standard air),	cm ⁻¹ , THz		
Power				
Calibration accuracy ⁵	± 0.5 dB (at ± 30 nm from	± 0.5 dB		
	780 nm ¹ , 1310 nm, and	(at ± 30 nm from 1310 nm and	d 1550 nm)	
	1550 nm)			
Flatness ¹	± 0.2 dB	± 0.2 dB		30 nm from any
	(1200 to 1600 nm)	(1270 to 1600 nm)		wavelength
	± 0.5 dB	± 0.5 dB		
	(700 to 1650 nm)	(1270 to 1650 nm)		
Linearity	± 0.3 dB	± 0.3 dB		Lines above –30 dBm
	(1200 to 1600 nm)	(1270 to 1600 nm)		
Polarization dependence	± 0.5 dB	± 0.5 dB		
	(1200 to 1600 nm)	(12/0 to 1600 nm)		
	± 1.5 dB '	± 1.0 dB (
Disalau assolution	(/UU to 1650 nm)	(1600 to 1650 nm)		
Display resolution				
Omits Constitution	αβm, mvv, μvv			
Sensitivity	00 dD		00 dD	
Single line input	-20 dBm	-40 dBm	-32 aBM (1270 to 1600 pm)	
		(12/0 to 1000 (1(1))	(1270 to 1600 mm)	_
	-25 UBIII (900 to 1200 pm)	-30 UBIII (1600 to 1650 pm)	-22 UDIII (1600 to 1650 pm)	
	(000 t0 1200 mm)			-
	(1200 to 1600 pm)			
	-30 dBm ⁶			_
	(1600 to 1650 nm)			
Multiple lines input ¹	30 dB below total input nower, but not less than single line input sensitivity			
Selectivity ¹ 25 dB spacing \geq 100 GHz 25 dB spacing $>$ 50 GHz 25 dB spacing $>$ 90 GHz				
,	10 dB spacing ≥ 30 GHz	10 dB spacing ≥ 15 GHz	10 dB spacing ≥ 10 GHz	

1. Characteristic.

2. 3. For 86122C number of laser lines may be limited by signal power requirements for accurate wavelength measurements.

Type tested means tested, but not warranted, for continuous operation.
 At 1550 nm.

Excluding polarization effects.
 Spurious free under Preset conditions.

Specifications (Continued)

	86120B	86120C	86122C	Notes
Input power				
Maximum displayed level	+10 dBm			Sum of all lines input
Maximum safe input level	+18 dBm			
Return loss				
 With non-angled (PC) 	35 dB			
connectors (Option 021)				
 With angled (APC) 	50 dB			
connectors (Option 022)				
 Measurement cycle time 	1.0 s	1.0 s		
- 86122C-100			0.5 s	
- 86122C-110			0.3 s	
 Maximum number of lines 	100	200	1000 ²	
Measurement modes	List by wavelength table, list b wavelength and total power	y power table, signal wavelengtl	h and power, average	Data logging and sorting by any parameter are included in the 86122C
Delta modes	Delta wavelength, delta power	, delta wavelength and power		
Built in automatic measuremen	nt applications			
Signal to noise ratio 1, 4				
Channel spacing				
– ≥ 200 GHz	> 35 dB with 100 averages			0.1 nm noise bandwidth,
– ≥ 100 GHz		> 35 dB with 100 averages	> 35 dB with 100 averages	lines above –25 dBm
– ≥ 50 GHz		> 27 dB with 100 averages	> 27 dB with 100 averages	
Drift				
	Maximum, minimum, total drift	(max-min) of wavelengths and	powers over time	
Fabry-Perot characterization				
		Mean wavelength, peak wavele full-width half maximum, peak	ength, mode spacing, amplitude, total power, sigma	
Coherence length ¹				
	 Fabry-Perot lasers 1 to 200 mm coherence length Accuracy to within ± 5%, 0.75 cycle time 			
Additional features				
	Power offset, power bars (on c user adjustable start and stop instrument states.	r off), user adjustable peak excu wavelength limits, graphical dis	ursion and peak threshold, play, save and recall	
Inputs/outputs				
Optical input	9 μm/125 μm single-mode fibe	er		
Rear panel connectors	GPIB, parallel printer port, AC	line	LAN, PS/2 for keyboard and mouse, SVGA and DVI for external monitor, GPIB, USB, AC Line	

1. Characteristic.

For 86122C number of laser lines may be limited by signal power requirements for accurate wavelength measurements.
 Type tested means tested, but not warranted, for continuous operation.

4. At 1550 nm.

5. Excluding polarization effects.

6. Spurious free under Preset conditions.

Specifications (Continued)

	86120B	86120C	86122C	Notes
Reliability				
Warranty	3 years	3 years	5 years	
Recommended re-calibration	2 years	2 years	2 years	
Dimensions and weight				
Dimensions (H x W x D)	140 mm x 340 mm x 465 (5.5 in x 13.4 in x 18.3 in	5 mm)	138 mm x 425 mm x 520 mm (5.2 in x 16.7 in x 20.5 in)	
	9 kg (19 lb)		14.5 kg (32 lb)	
Environmental				
Operational				
Temperature	0 to +55 °C		15 to 35 °C	
Humidity ³	< 95% R.H. at +40 °C, 5	day soak	< 75% R.H. at 35 °C	
			Indoor use only	
Shock ³	300 g		120 g	Half sine, 2 msec pulse
Vibration ³	5 g rms		2 g rms	Random, 5 Hz to 500 Hz,
	0.75 g (0 to peak)		0.5 g (0 to peak)	10 min./axis Sine, 5 Hz to 500 Hz, 1 octave/min.
Storage				
Temperature	-40 °C to +70 °C			
Humidity ³	90% R.H. at +65 °C for 2	24 hrs.	95% R.H. at +40 °C 5 day cycle	Non-condensing
Power requirements				
Voltage and frequency	100 V / 115 V / 230 V / 2	240 V~, 50 Hz / 60 Hz	100 V / 115 V / 230 V / 240 V~, 50 Hz / 60 Hz	
Maximum power	70 W max (125 VA max)		310 VA max	

Characteristic.
 For 86122C number of laser lines may be limited by signal power requirements for accurate wavelength measurements.

Type tested means tested, but not warranted, for continuous operation.
 At 1550 nm.

5. Excluding polarization effects.

6. Spurious free under Preset conditions.

General Characteristics

The 8612x wavelength meters contain HeNe reference lasers, which have limited operating lifetimes, like all gas-discharge lasers. With the latest enhancement of the reference lasers used in the new 86122C, the average laser lifetime has doubled. Together with the 2-year recommended re-calibration period and the included 5-year warranty (3 years for 86120B, 86120C), this helps minimizing planned and unplanned downtimes and cost of ownership.

Ordering Information

For the most up-to-date ordering information, please contact your Keysight sales representative.

Connector interfac	es (order separately)
81000FI	FC connector interface (FC/PC)
81000HI	E-2000 connector interface
81000KI	SC connector interface
81000LI	LC connector interface
81000MI	MU connector interface
81000NI	FC connector interface (FC/APC with narrow key)
81000SI	DIN connector interface
81000VI	ST connector interface
86120B/C Multi-w	avelength meter
Optical connector	S
86120x-021	Straight (non-angled) connector interface-PC
86120x-022	Angled contact interface-APC
Assessmins	
Accessories	
86120x-AXE	Rack flange kit with handles
Accessories 86120x-AXE 86120x-IA4	Rack flange kit with handles Rack flange kit without handles
86120x-AXE 86120x-IA4 86120x-UK6	Rack flange kit with handlesRack flange kit without handlesCommercial calibration certificate with test data
86120x-AXE 86120x-IA4 86120x-UK6 Warranty and calib	Rack flange kit with handles Rack flange kit without handles Commercial calibration certificate with test data oration
86120x-AXE 86120x-IA4 86120x-UK6 Warranty and calib R-51B-001-5C	Rack flange kit with handlesRack flange kit without handlesCommercial calibration certificate with test dataorationWarranty Assurance Plan – Return to Keysight –
86120x-AXE 86120x-IA4 86120x-UK6 Warranty and calib R-51B-001-5C	Rack flange kit with handlesRack flange kit without handlesCommercial calibration certificate with test dataorationWarranty Assurance Plan – Return to Keysight – 5 years
Accessories 86120x-AXE 86120x-IA4 86120x-UK6 Warranty and calib R-51B-001-5C R-50C-011-3	Rack flange kit with handlesRack flange kit without handlesCommercial calibration certificate with test dataorationWarranty Assurance Plan – Return to Keysight – 5 yearsCalibration Assurance Plan – Return to Keysight –
Accessories 86120x-AXE 86120x-IA4 86120x-UK6 Warranty and calib R-51B-001-5C R-50C-011-3	Rack flange kit with handlesRack flange kit without handlesCommercial calibration certificate with test datavrationWarranty Assurance Plan – Return to Keysight – 5 yearsCalibration Assurance Plan – Return to Keysight – 3 years
Accessories 86120x-AXE 86120x-IA4 86120x-UK6 Warranty and calit R-51B-001-5C R-50C-011-3 R-50C-011-5	Rack flange kit with handlesRack flange kit without handlesCommercial calibration certificate with test dataorationWarranty Assurance Plan – Return to Keysight –5 yearsCalibration Assurance Plan – Return to Keysight –3 yearsCalibration Assurance Plan – Return to Keysight –
Accessories 86120x-AXE 86120x-IA4 86120x-UK6 Warranty and calib R-51B-001-5C R-50C-011-3 R-50C-011-5	Rack flange kit with handlesRack flange kit without handlesCommercial calibration certificate with test dataorationWarranty Assurance Plan – Return to Keysight –5 yearsCalibration Assurance Plan – Return to Keysight –3 yearsCalibration Assurance Plan – Return to Keysight –5 yearsCalibration Assurance Plan – Return to Keysight –5 years
Accessories 86120x-AXE 86120x-IA4 86120x-UK6 Warranty and calit R-51B-001-5C R-50C-011-3 R-50C-011-5 R-50C-021-3	Rack flange kit with handlesRack flange kit without handlesCommercial calibration certificate with test dataorationWarranty Assurance Plan – Return to Keysight – 5 yearsCalibration Assurance Plan – Return to Keysight – 3 yearsCalibration Assurance Plan – Return to Keysight – 5 yearsCalibration Assurance Plan – Return to Keysight – 5 yearsANSI Z540-1-1994 Calibration – 3 years

86122C Multi-way	velength meter
86122C-100	Wavelengths 1270 nm to 1650 nm, \pm 0.2 ppm
86122C-110	Wavelengths 1270 nm to 1650 nm, Fast Update,
	± 0.2 ppm
Optical connecto	rs
86122C-021	Straight (non-angled) connector interface-PC
86122C-022	Angled contact interface-APC
Accessories	
86122A-1CM	Rack mount kit without handles
86122A-1CN	Handle kit
86122A-1CP	Rack mount kit plus handles
86122C-UK6	Commercial calibration certificate with test data
Calibration	
R-50C-011-3	Calibration Assurance Plan – Return to Keysight –
	3 years
R-50C-011-5	Calibration Assurance Plan – Return to Keysight –
	5 years
R-50C-021-3	ANSI Z540-1-1994 Calibration – 3 years
R-50C-021-5	ANSI Z540-1-1994 Calibration – 5 years

CLASS 1 LASER PRODUCT (IEC 60825-1 / 2007)

Optical Instruments Online Information

Optical test instruments	www.keysight.com/find/oct
Lightwave component analyzers	www.keysight.com/find/lca
Polarization solutions	www.keysight.com/find/pol
Spectral analysis products	www.keysight.com/find/mwm
Electro-optical converters	www.keysight.com/find/ref
Optical test instruments accessories	www.keysight.com/find/octaccessories
Firmware and driver download	www.keysight.com/find/octfirmware
Keysight photonic discussion forum	www.keysight.com/find/photonic_forum

myKeysight

myKeysight

Three-Year Warranty

www.keysight.com/find/mykeysight

A personalized view into the information most relevant to you.



www.keysight.com/find/ThreeYearWarranty

Keysight's commitment to superior product quality and lower total cost of ownership. The only test and measurement company with three-year warranty standard on all instruments, worldwide.



Keysight Assurance Plans www.keysight.com/find/AssurancePlans

Up to five years of protection and no budgetary surprises to ensure your instruments are operating to specification so you can rely on accurate measurements.



www.keysight.com/go/quality

Keysight Technologies, Inc. DEKRA Certified ISO 9001:2008 Quality Management System

www.keysight.com/find/service

Keysight Infoline

Keysight Infoline

Keysight's insight to best in class information management. Free access to your Keysight equipment company reports and e-library.

Keysight Channel Partners

www.keysight.com/find/channelpartners

Get the best of both worlds: Keysight's measurement expertise and product breadth, combined with channel partner convenience.

www.keysight.com/find/mwm

For more information on Keysight Technologies' products, applications or services, please contact your local Keysight office. The complete list is available at: www.keysight.com/find/contactus

Americas

Canada	(877) 894 4414
Brazil	55 11 3351 7010
Mexico	001 800 254 2440
United States	(800) 829 4444

Asia Pacific

Australia	1 800 629 485
China	800 810 0189
Hong Kong	800 938 693
India	1 800 11 2626
Japan	0120 (421) 345
Korea	080 769 0800
Malaysia	1 800 888 848
Singapore	1 800 375 8100
Taiwan	0800 047 866
Other AP Countries	(65) 6375 8100

Europe & Middle East

United Kingdom

For other unlisted countries: www.keysight.com/find/contactus (BP-04-23-15)

0800 0260637



This information is subject to change without notice. © Keysight Technologies, 2013 - 2015 Published in USA, July 6, 2015 5988-5422EN www.keysight.com