High Power Fiber Lasers

alta



nLIGHT alta™ is the first in a line of next generation high power fiber lasers. Designed to meet the performance and reliability requirements for industrial applications, nLIGHT alta™ incorporates several improvements over other commercially available fiber lasers:

- Improved Cutting and Welding Performance: nLIGHT alta™ is capable of delivering a modulation rate up to 50 kHz and rise and fall time of less than 10 µs. Enabled by next generation electronics, these capabilities allow faster piercing, faster processing of fine features, and better processing quality through minimal heat affected zone.
- Back Reflection Isolation: nLIGHT's novel back reflection isolation technology allows uninterrupted full power processing of highly reflective materials.
- Design-for-Service: nLIGHT alta[™] incorporates a unique, proprietary fiber laser architecture that enables tool integrators or end users to manage common field service events, which results in higher machine uptime, lower cost of ownership and an improved customer experience.

The nLIGHT alta $^{\text{\tiny{M}}}$ fiber laser platform is designed and manufactured in the U.S., leveraging nLIGHT's vertically integrated high brightness laser diode and fiber technology, and is supported through a global network of sales and service staff. nLIGHT alta $^{\text{\tiny{M}}}$ - the next generation of fiber lasers.

Features

- Advanced cutting and welding performance
- Failsafe processing of highly reflective materials
- Proprietary design for high uptime and easy service
- Durable to harsh environmental conditions
- Powers of 2 kW, 3 kW and 4 kW

Applications

- Cutting
- Welding
- Hardening / cladding
- Additive manufacturing

Typical Device Specifications

Optical	Units				
Mode of operation		CW/QCW			
Polarization			Random		
Maximum average power (CW)	W	2000	3000	4000	
Maximum peak power (Modulated)	W	2000	3000	4000	
Power tunability	%	5 – 100			
Power variation (8 hr)	%		≤ 1		
Modulation frequency	kHz		≤ 50		
Rise/fall times	μs		≤ 10		
Beam quality (multi-mode options)*	mm-mrad	≤ 2 w ≤ 4 w	Tailored to customer need: ≤ 2 with 50 μm fiber ≤ 4 with 100 μm fiber ≤ 8 with 200 μm fiber		
Wavelength	nm		1080 ± 10		
Electrical					
Operating voltage	VAC	3	3-phase 380-420		
Operating voltage frequency	Hz		50/60		
Control interface		Externa	External hardware control/RS- 232/Ethernet		
Mechanical					
Dimensions (mm)		815 w x 1000 h x 1275 d			
Optical fiber		10 m, 20 m, 30 m, QBH connector standard, other options available			
Fiber-to-fiber coupler/beam switch module	oupler/beam switch module		Optional		
Cooling method		Water			
General condition					
Operating temperature*	°C		+10 to +40		
Storage temperature	°C		-10 to +60		
Relative humidity*	%		10 to 80		

^{*}Non-condensing

Laser Safety

This laser product does NOT comply with IEC 60825-1 or 21CFR1040.10/21CFR1040.11 and is solely intended to be integrated into a laser product certified by the Purchaser. The Purchaser acknowledges that their product must comply with the applicable regulations before it can be sold to an end user.







Notice

nLIGHT continually improves its products to provide our customers with outstanding quality and reliability. nLIGHT may make changes to specifications and product descriptions at any time, without notice. In addition, nLIGHT offers a limited warranty to ensure customer satisfaction. For complete details, please contact your nLIGHT sales representative.